Shihlin Sürücülerde Son Hata Kaydı Görüntüleme

SA3, SE3, SC3, SL3, SF3 sürücülerde son 12 hata kaydı görüntüleyebilmek için görüntülenmek istenen hata sayısı **06-42 (P.290)**'ye (SS2 serisi için P.288) 1 girip **06-43**'ten (SS2 serisi için P.289) verdiği hata koydu görüntülenir. Örneğin **06-42**: 1 yaptıktan sonra **06-43**: 16 görüntüleniyor ise OC1 vermiş demektir.

Parameter	Name	Default	Setting Range	Content	
06-40 P.288	Alarm record code query	1	0 ~ 12	06-40 (P.288) value 1~12 corresponds to 06-41(P.289)'s alarm E1~E12.	
06-41 P.289	Alarm record code display	Read only	Read only		
06-42 P.290	Alarm record message query	0	0 ~ 10	Alarm message of No. 06-40 (P.288)	06-42 (P.290) =1, 06-43 (P.291) displays frequency when 06-40 (P.288) alarm. 06-42 (P.290) =2, 06-43 (P.291) displays current when 06-40 (P.288) alarm. 06-42 (P.290) =3, 06-43 (P.291) displays output voltage when 06-40 (P.288) alarm. 06-42 (P.290) =4, 06-43 (P.291) displays temperature rising accumulation rate when 06-40 (P.288) alarm. 06-42 (P.290) =5, 06-43 (P.291) displays PN voltage when 06-40 (P.288) alarm. 06-42 (P.290) =6, 06-43 (P.291) displays total inverter operation time when 06-40 (P.288) alarm. 06-42 (P.290) =7, 06-43 (P.291) displays inverter operation status code when 06-40 (P.288) alarm. 06-42 (P.290) =8, 06-43 (P.291) displays dates (years and months) when 06-40 (P.288) alarm. 06-42 (P.290) =9, 06-43 (P.291) displays dates (days and hours) when 06-40 (P.288) alarm. 06-42 (P.290) =10, 06-43 (P.291) displays dates (minutes and seconds) when 06-40 (P.288) alarm.
06-43 P.291	Alarm record message display	Read only	Read only		

Setting Alarm query function

Alarm number corresponded alarm condition:

Abnormal code	Alarm type	Abnormal code	Alarm type	Abnormal code	Alarm type	Abnormal code	Alarm type	Abnormal code	Alarm type
00	No alarm	48	THT	98	OL2	179	SCP	214	dv4
16	OC1	49	THN	99	OMD	192	CPU	215	dv3
17	OC2	50	NTC	117	EF	193	CPR	216	dv1
18	OC3	64	EEP	128	GF	195	EbE1	217	dv2
19	OC0	66	PID	129	AEr	208	PG0	219	OS
32	OV1	82	IPF	144	OHT	209	PG1	220	OPE
33	OV2	84	LF	145	YDE	210	PG2		
34	OV3	85	HDC	160	OPT	211	PG3		
35	OV0	86	ADE	161	PUE	212	bEb		
36	Lv0	97	OLS	162	CbE	213	PTC		

Note: If PU302 is used, these functions will not work: 06-42(P.290) =8, 9, 10. Select 06-43 (P.291) to display years/months, days/hours, minutes/seconds when alarm occurs.

Hata anında:

06-56: Çıkış frekansı
06-57: Çıkış akımı
06-58: Çıkış voltajı
06-60: PN arası voltaj görüntülenebilir.