SDE Serisi Servo Sürücü CN3 RS485 Konnektörü Pin Açıklamaları

CN3 RS485 Konnektörü Pin Açıklamaları



CN3 connector (female type)

Pin NO	Sign	Function description
1~3	GND	Signal ground.
4	RS-485-A	Data are transmitted in differential line driver. Line driver A.
5	RS-485-A	Data are transmitted in differential line driver. Line driver B.
6~8	GND	Signal ground.